

IMPORTANT – READ FIRST

Do Not Store Plugged in to Bose Headphones!


Store Harmony in the left side pocket of the UFlyMike case.

Do not disconnect or connect while headphones are on your head!

To avoid damaging your Harmony or headphones, care must be taken when connecting and disconnecting the Harmony from the Headphone.

To Connect: Grasp the Harmony at the feather logo and gently push straight in (push until you feel/hear it snap into place). The Harmony will fit tightly and will not fall out when installed correctly.

To Disconnect: Grasp the Harmony at the feather logo and gently pull straight out.



**DISCONNECTING IMPROPERLY CAN BEND OR
BREAK THE PLUG. REPAIRS OF DAMAGED
PLUGS DUE TO USER ERROR ARE NOT
COVERED UNDER WARRANTY.**

QC45 Volume and Echo Issue

Important: When using an audio jack, Bose QuietComfort and QuietComfort 45 headphones default to low volume. Be sure to raise the volume after connecting the Harmony system.

To set volume correctly:

1. Plug in the Harmony system.
2. Turn on the Bose QC45 headphones.
3. Press the plus (+) button on the right ear cup to set the headphone volume to maximum.
4. After your trip, turn off the headphones and unplug the Harmony.

Note: Use the Harmony AV box's volume controls to adjust listening levels as needed. Keeping QC45 volume at maximum prevents echo and ensures optimal performance.

A Video walk-through of these steps is also available on our Youtube channel. You can find the video by following this QR Code.

